

365 Flashing Membrane 396 Sheathing Tape 369 DrainEdge™ WaterMaster™ Accessories



365 Flashing Membrane



396 Sheathing Tape

365 FLASHING MEMBRANE


- Self sealing membrane for sills and rough opening flashing

396 SHEATHING JOINT TAPE

- Non-woven fabric used to tape joints
- Used with any Parex USA water resistive barrier coatings to flash terminations and rough openings

369 DrainEdge™

- Perforated, corrugated Tyvek* material that allows drainage at the head of system penetrations



369 DrainEdge™

PAREXUSA

DESCRIPTION:

365 FLASHING MEMBRANE

- 365 Flashing Membrane is a self-sealing rubberized asphalt membrane that functions as a moisture and air barrier. It is 40 mils (1.0mm) thick and black in color. It can be applied to various substrates such as wood, metal, gypsum sheathing and to house wrap and other weather resistive barriers. The 365 Flashing Membrane is unique: it is faced with a non-woven, integrally bonded fabric that enables adhesion of adhesives. It functions as a seal and flashing at sills of rough openings, deck framing, etc., interfacing with the building substrate and other weather resistive barriers.
- Unit Size (sold only by the box):
 - 3 in x 100 ft. (7.6cm x 30.5m) Rolls per Box 12.
 - 6 in x 100 ft. (15cm x 30.5m) Rolls per Box 8.
 - 12 in x 100 ft. (30cm x 30.5m) Rolls per Box 4.
- Thickness 40 mil (1.0mm):
 - Tensile Strength (Polyester Fabric) 1400 psi ASTM-D412.
 - Elongation (Rubber Asphalt Adhesive) over 500% ASTM-D412.
 - Moisture Vapor Transmission Rate 0.1 perm max. ASTM E96.

396 SHEATHING TAPE

- Description and Use: Non-woven fabric used to tape the joints of the sheathing boards to which a Parex USA water resistive barrier is applied.
- Embed in Parex USA water resistive barrier coatings to seal to flashing and at terminations and rough openings per Parex USA installation instructions.
- Unit Size:
 - 396.4 4 in. x 500 ft. (10.16 cm x 152.4 m)
 - 396.6 6 in. x 500 ft. (15.25 cm x 152.4 m)
 - 396.9 9 in. x 500 ft. (22.86 cm x 152.4 m)

369 DrainEdge™

FEATURES:

- Speeds and simplifies application of the Parex USA EIFS with Drainage
- Eliminates need for pre-wrapping or rasping the back of boards at terminations
- Eliminates the need for mineral wool and track at terminations

USES:

- Termination of system at heads of penetrations
- Termination at wall base in lieu of track, especially for curved walls

COMPOSITION:

- Spunbonded polyolefin
- Color: White

TESTING:

- UBC 26-9/NFPA 285 ISMA apparatus fire-test at head of opening. Qualified for non-combustible construction.

X

PACKAGING:

- Individual 200 ft. roll in a carton
 - Width 7 in. (2.8 cm)

STORAGE:

- Store enclosed out of sunlight
- Protect from dirt and moisture

LIMITATION:

- Metal head flashing must be used behind DrainEdge

INSTALLATION:

- Before Installing 369 DrainEdge:
 - Flashing at heads of openings must be in place prior to application of Parex USA water resistive barrier coatings and 396 Sheathing Joint Tape.
 - Parex USA water resistive barrier coatings with 396 Sheathing Joint Tape embedded at metal head flashing must be in place and dry.

■ 369 DrainEdge Installation:

- Cut off and discard the unperforated material at the beginning of the roll (approximately 6-7 in. (15.2-17.8 cm).
- Place 369 DrainEdge over the head flashing so that 2 in. (5.1 cm) of the lower edge of the 369 DrainEdge will be exposed after the EPS insulation is installed over it. 5 in. (12.7 cm) of 369 DrainEdge will be behind the EPS once the EPS is installed.

DO NOT STRETCH 369 DRAINEDGE DURING INSTALLATION.

- Secure any 369 DrainEdge with any Parex USA Adhesive or corrosion resistant staples approximately every 16 in. (40.6 cm).

■ Backwrap Mesh Installation:

DO NOT EMBED BACKWRAP MESH IN BASECOAT OVER 369 DRAINEDGE.

- Apply 355 Standard Mesh over 369 DrainEdge and secure its top edge with dabs of any Parex USA Adhesive or corrosion-resistant staples approximately every 16 in. (40.6 cm).
- Cut backwrap mesh wide enough to wrap 6 in. (15.2 cm) in back of the EPS and a minimum of 5 in. (12.7 cm) onto the outer face of the EPS.
- Install EPS, basecoat, and finish coat.
- Trim off the 2 in. (5.1 cm) of exposed 369 DrainEdge with a sharp knife after finish coat is dry.

PAREXUSA
www.parexusa.com

Corporate Office

Parex USA, Inc.
4125 E. La Palma Ave., Suite 250
Anaheim, CA 92807
(866) 516-0061
Tech Support: (800) 226-2424

Facilities

Redan, GA
Riverside, CA
French Camp, CA
Colorado Springs, CO
Albuquerque, NM
San Antonio, TX
Wilkes Barre, PA
Ft. Pierce, FL

